



Ball mill inspection procedure



Tim Nowack
Senior Process Engineer

Christian Pfeiffer Maschinenfabrik GmbH



General

**Material
sampling**

**Longitudinal
sampling**

Filling degree

Material level

**Internals
condition**

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

General:

The process engineer should be the doctor of the system.

The “doctor” is required for:


- 1) implementation of “Health checks”
→ Regular action
- 2) urgent investigations of actual
process problems
→ Non-regular action

**This presentation focuses on the regular
“Health check” procedure.**

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



General

Material
samplingLongitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A


*The Green Tree
Convention Center*

General:

The “Health checks” consist of standard measurements on a frequent basis

Type of measurement:	12 months schedule											
Circuit mat. granulometry				●								
Mill longitudinal sieving	●			●			●			●		
Ball charge filling degree	●			●			●			●		
Mill material level	●			●			●			●		
Mill internal conditions	●			●			●			●		
Ball charge sampling				●								
Separator Tromp curve				●								
Separator ventilation				●								
Mill ventilation				●								
Weigh feeder calibration				●								
Instrument verification	●			●			●			●		
Control loop verification				●								

Main annual audit



General

**Material
sampling**

**Longitudinal
sampling**

Filling degree

Material level

**Internals
condition**

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

Navigation

I.E.E.E West Coast

Conference 2009

8th – 9th October

Victorville/ CA

U.S.A

The Green Tree

Convention Center


General:

“Healts checks” are important in order to:

- build up a knowledge and data base about the system performance
- record the data and display them in trends for fast and easy diagnostic of problems

The main advantage:

Knowledge basis allows to investigate the root cause of problems and to avoid problems by early reaction based on the trend results.



General

**Material
sampling**

**Longitudinal
sampling**

Filling degree

Material level

**Internals
condition**

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

Navigation

I.E.E West Coast


Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*

General:

For each measurement make sure you have:

- **design data of the machines/equipment available.**
- **constant/stable operation condition for at least 2 hours.**
- **recorded the actual operation data like:**
 - Production rate [t/h], Product type, composition [M-%]
 - Actual and target fineness of product [Blaine or Residue]
 - Actual mass flow rate (e.g. separator grits, water demand, etc.)
 - Electrical power consumption of the main equipment
 - Actual operation parameter of the main equipment (e.g. separator speed, damper positions)



General

Material
sampling

Longitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve


Ventilation

Weighfeeder

Instrument

Control loop

Circuit material granulometry: Sampling points



Navigation

I.E.E.E West Coast

Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



Circuit material granulometry:

Sampling point:	☀	🕒	Procedures	
Clinker feed	10 kg	1 x per Test	🔧	Sieving 50, 25, 16, 8, 4, 2, 1, [mm]
Gypsum feed			H ₂ O	
Additive No.1 feed			H ₂ O	
Additive No. 2 feed			H ₂ O	
Mill outlet material	0.5 kg	1 x every hour	🔧	Pre-screening with 450 µm sieve
Separator feed material			🔧	
Separator grits material			🔧	
Separator fines cyclone 1			🔧	PSD from 1-450 µm with Laser equipment (e.g. Cilas, Malvern, Sympatec)
Separator fines cyclone 2			🔧	
Separator fines mix			🔧	
Filter dust 1 (weighfeeder)			🔧	
Filter dust 2 (circuit dedusting)			🔧	Fineness acc. to Blaine [cm ² /g]
Filter dust 3 (mill dedusting)			🔧	
Cement			🔧	

General

Material sampling

Longitudinal sampling

Filling degree

Material level

Internals condition

Ball charge

Trompcurve

Ventilation

Weighfeeder


Instrument

Control loop

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



General

Material
sampling

Longitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation


Weighfeeder

Instrument

Control loop

Longitudinal sampling:


Sampling points at **crash stop**



Sample weight:

1st compartment: 1-2 kg


2nd compartment: 0.5 kg



Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



General

Material
samplingLongitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation


Weighfeeder

Instrument

Control loop

Ball charge filling degree:

Measurement by free height



1. Measure average internal diameter, D_i
2. Measure height, h , in three different points along axis for each grinding compartment


For best results the measurement takes place in an empty mill (mill feed stopped for approx. 10 min).

Navigation

I.E.E.E West Coast

Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*





General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop

Mill material level:

Inspection only at **crash stop**

Record the material level approx. each meter along axis




**Good material level
for 1st compartment**

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*




General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop

Mill material level:

Inspection only at **crash stop**

Record the material level approx. each meter along axis



	Too high = > 50mm above charge
	Good = approx. 20 mm above charge
	Moderate = equal with ball charge
	Too low = >> 50 mm below charge




**Good material level
for 2nd compartment**

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center




General
Material
sampling
Longitudinal
sampling
Filling degree
Material level
Internals
condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop

Mill material level:

Inspection only at **crash stop**


Record the material level before and after **transfer points**



Navigation

I.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



Mill internals condition:

CRASH STOP INFORMATION:

Type of product: **OPC**

Total mill feed:	n.a.	[t/h]
Fresh feed:	n.a.	[t/h]
Coarse return:	n.a.	[t/h]




Finish mill No. 2
 \varnothing 3,5 m x 9,6 m

Main mill drive:

power installed	1495	[kW]
power absorbed	n.a.	[kW]
mill speed	16,72	[r.p.m.]
critical speed	72,67	[%]

Free height calculation:


Pabs= 1247 kW



Navigation

I.E.E.E West Coast
 Conference 2009
 8th – 9th October
 Victorville/ CA
 U.S.A

*The Green Tree
 Convention Center*



Mill internals condition:

General

Material
sampling

Longitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

MILL SHELL LINING SYSTEM:

1st compartment:

Type of lining: Wave liners (5 rows)
Type of fastening: bolted
Condition: Worse / Rem. lifting height 50-65mm
Remarks: Many broken plates - scraps in gaps
None DIN type

Measurement Point	Free Height above charge	Material level	Ball sizes
1	2,260	one side approx. 30mm below	90 - 50
2	-	-	-
3	-	-	-
4	-	-	-
AVG.	2,260	FG = 28,2%	-

2nd compartment:

Type of lining: Wave liners (3 rows)
Type of fastening: bolted
Condition: Good condition - some
Remarks: Average lifting height: 50-65mm
Poor Material level

Measurement Point	Free Height above charge	Material level	Ball sizes
-------------------	--------------------------	----------------	------------

3rd compartment:

Type of lining: Drag Peb lining with Da
Type of fastening: semi bolted / Danula rim
Condition: Mechanical good condition
Remarks: Small balls in gaps betw plates

MILL DIAPHRAGMS:

HEAD LINER



	Inner diameter <----> outer diameter			
Lining ring	1	2	3	4
Number of plates per ring	8	16	16	16
Base Thickness	x	x	x	x
Residual Thickness	65 mm	40-70	50-60	50-70
Lifter height	n.a.	n.a.	n.a.	n.a.
Number of bolts per plate	2	2	2	2
Remark	-	worn out broken plates replaced plates	-	-
Ø mill inlet	1,005 mm			
Type of mill head	conical			

INTERMEDIATE DIAPHRAGM NO. 1



	Inner diam
Lining ring	1
Number of plates per ring	8
Base Thickness	x
Residual Thickness	30-40
Lifter height	n.a.
Number of bolts per plate	4
Slot type	circum.
Slot width	2-9.5
Open area	~95%
Remark	mesh Ø 490mm
Material flow control	
Width of diaphragm	
Condition of structure	
Ø-Centre opening	


Name	MILL DATA SHEET	Installation	Flr
Now		Mill Dimensions	Ø
Date	Project No.	Customer	
09.06.2005	Country	Plant	

MILL DIAPHRAGMS:



INTERMEDIATE DIAPHRAGM NO. 2

	Frontside				Backside			
	inner diameter <----> outer diameter				inner diameter <----> outer diameter			
Lining ring	1	2	3	4	1	2	3	4
Number of plates per ring	8	16	-	-	8	16	-	-
Base Thickness	x	x	-	-	x	x	-	-
Residual Thickness	20-40	20-35	-	-	65-80	65-80	-	-
Lifter height	n.a.	n.a.	-	-	n.a.	n.a.	-	-
Number of bolts per plate	4	3	-	-	4	3	-	-
Slot type	circum.	circum.	-	-	n.a.	n.a.	-	-
Slot width	4-10	5-11	-	-	n.a.	n.a.	-	-
Open area	100%	95%	-	-	n.a.	n.a.	-	-
Remark	mesh Ø 490mm	-	-	-	-	-	-	-
Material flow control	n.a.							
Width of diaphragm	x							
Condition of structure	mechanical acceptable condition							
Ø-Centre opening	1000 mm				1010 mm			



DISCHARGE DIAPHRAGM



	inner diameter <----> outer diameter			
Lining ring	1	2	3	4
Number of plates per ring	8	16	-	-
Base Thickness	x	x	-	-
Residual Thickness	25-40	20-35	-	-
Lifter height	n.a.	n.a.	-	-
Number of bolts per ring	4	4	-	-
Slot type	radial	radial	-	-
Slot width	5-6	5-8	-	-
Open area	100%	~80%	-	-
Remark	screen with small free area	-	-	-


Width of diaphragm	x
Condition of structure	good
Ø-Centre opening	x

Name	MILL DATA SHEET	Installation	Finish mill No. 2
Now		Mill Dimensions	Ø 3.5 m x 9.6 m
Date	Project No.	Customer	
09.06.2005	Country	Plant	


Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center



Mill internals condition:


General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition 
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop




Navigation

I.E.E West Coast
 Conference 2009
 8th – 9th October
 Victorville/ CA
 U.S.A



*The Green Tree
 Convention Center*



General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge 
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop

Ball charge sampling:


Solution 1) Total sorting of ball charge



Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop


Navigation

I.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center

Ball charge sampling:

Solution 2) Analysing the actual grinding media composition by spot samples.



1st compartment:

50 balls per sample

2nd compartment:

200 balls per sample

Christian Pfeiffer
Systems and components

AVG. PIECE WEIGHT

Input Table

Date: 23.02.2006

Prepared by: Now


CUSTOMER DATA:

Project-No.:	33.420
Project:	-
Customer:	-
Plant:	-
Installation:	Ø2.4m x 5.0m with QDK 8,5-F
Compartment:	Monochamber (1/3 lifter - 2/3 class.)

GRINDING BALLS

Ball - Ø	60	50	40	30	25	20
Std.	886 g	513 g	262 g	111 g	64 g	33 g
Max	1400,0 g	681,0 g	374,0 g	176,0 g	80,0 g	44,0 g
Min	682,0 g	375,0 g	177,0 g	81,0 g	45,0 g	14,0 g

Piece	Mass					
1	891,8 g	891,8 g				
2	886,2 g	886,2 g				
3	879,6 g	879,6 g				
4	878,0 g	878,0 g				
5	873,5 g	873,5 g				
6	873,3 g	873,3 g				
7	861,0 g	861,0 g				
8	860,6 g	860,6 g				
9	858,2 g	858,2 g				



Ball charge sampling:

Solution 2) Analysing the actual grinding media composition by spot samples.

General

Material
sampling

Longitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation


Weighfeeder

Instrument

Control loop

RESULTS OF GRINDING MEDIA SAMPLING

Ball Ø	Sampling Point														
	1			2			3			4			5		
	pc.	weight	mass-%	pc.	weight	mass-%	pc.	weight	mass-%	pc.	weight	mass-%	pc.	weight	mass-%
60	24	19920	53,56%	3	2552	10,54%	3	2353	9,68%	0	0	0,00%	0	0	0,00%
50	23	11112	29,88%	20	9269	38,28%	10	4651	19,13%	0	0	0,00%	0	0	0,00%
40	18	4293	11,54%	35	8468	34,97%	19	4592	18,88%	5	1209	11,58%	4	952	4,96%
30	13	1384	3,72%	28	2997	12,38%	59	6328	26,02%	28	2943	28,19%	63	6617	34,46%
25	8	481	1,29%	14	835	3,45%	73	4369	17,97%	66	3923	37,57%	144	8576	44,67%
20	0	0	0,00%	3	93	0,39%	66	2025	8,33%	76	2366	22,66%	98	3056	15,91%
Total	86	37190	100,00%	103	24215	100,00%	230	24316	100,00%	175	10441	100,00%	309	19200	100,00%




Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center

Name	AVG. PIECE WEIGHT	Installation	-
Now		Mill dimensions	-
Date	Project. No. 33.420	Customer	-
23.02.2006	Country -	Plant	-





General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop




Navigation


I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*

Separator tromp curve:

Define the sampling points





General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop




Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center

Separator tromp curve:


Define the sampling points



and

Check the stable
condition of the circuit

Record all main operation
parameters



General

Material
samplingLongitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation

Weighfeeder


Instrument

Control loop

Separator tromp curve:

Define the sampling points


Sampling point:	☀	🕒	Procedures	
Separator feed material	0.5 kg	1 x every hour	🕒	Pre-screening with 450 μ m sieve
Separator grits material			🕒	PSD from 1-450 μ m with Laser equipment (e.g. Cilas, Malvern, Sympatec)
Separator fines cyclone 1			🕒	Fineness acc. to Blaine [cm ² /g]
Separator fines cyclone 2			🕒	



Navigation

I.E.E.E West Coast

Conference 2009
8th – 9th October
Victorville/ CA
U.S.AThe Green Tree
Convention Center



General

Material
samplingLongitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A


*The Green Tree
Convention Center*

Separator Ventilation:

Basics: **Air flow measurement**


Select your equipment

Prandtl-Pitot Tube




- No correction factor needed
- Easy to operate within 15° angle
- Only in low vortex channel
- Not for high dust loaded channels

S-Type Tube



- Correction factor required (~0.84)
- Misalignment results in mistakes
- Preferred for high dust loaded channels




General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop


Separator Ventilation:

Measurement points:

Separator circuit with cyclones



Separator circuit with filter




● = Air flow, Static pressure, Temperature

▲ = Static pressure, Temperature


Navigation

I.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center



Mill Ventilation:



Remark: Consider minimum 10% false air intake after mill.

● = Air flow, Static pressure, Temperature

▲ = Static pressure, Temperature

General

Material
sampling

Longitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation

Weighfeeder


Instrument

Control loop

Navigation

I.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



General

Material
sampling

Longitudinal
sampling

Filling degree

Material level

Internals
condition

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

Navigation

I.E.E West Coast


Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*

Weigh Feeder Calibration:

a) Static calibration - feeder not in operation


- Zero-point - adjustment (local control box, no load)
- Span adjustment with calibration weight (local control box)



b) Calibration with feeder in operation (preferred if possible)

- operate weigh feeder with defined setpoint and load material into truck for e.g. 10 minutes, while mill is shut down
- weigh truck empty and loaded, calculate throughput and adjust controller if necessary





General

**Material
sampling**

**Longitudinal
sampling**

Filling degree

Material level

**Internals
condition**

Ball charge

Trompcurve

Ventilation

Weighfeeder

Instrument

Control loop

Instrument Verification:

1) Electronically

- Check and adjust zero-point and span with e.g. mA-transmitter

2) Operation check

- Compare control room indication with local manual measurement of temperature, pressure and flow

→ Adjust transmitters

Navigation

I.E.E West Coast

Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

*The Green Tree
Convention Center*



General
Material sampling
Longitudinal sampling
Filling degree
Material level
Internals condition
Ball charge
Trompcurve
Ventilation
Weighfeeder
Instrument
Control loop

Navigation

I.E.E.E West Coast
Conference 2009
8th – 9th October
Victorville/ CA
U.S.A

The Green Tree
Convention Center

Control loop Verification:


1) Operation check

- record process parameters with control loop in operation over period of e.g. 6-8 hours with constant production
- record mill power consumption at counter (kWh)


➔ Adjust control loop parameters if necessary

Information on:

- Available information at the CCR
- Control system
- Control strategy
- First impression on operation
- Circuit stability



Thank you for your attention



Questions?

